
TROUT & WATERSHED DEVELOPMENT

Introduction

Few waterways are as important as a trout stream and none are more sensitive to the impacts of shopping centers, highways, and other forms of watershed development. As illustrated in the graph below, a typical warmwater stream will begin exhibiting signs of stress when 8% of the watershed is covered with houses, streets, parking lots and other *impervious* surfaces. But one recent study showed that healthy brook trout streams have a watershed imperviousness of no more than 2%! Significant declines in brook trout populations occur at 7% impervious. Sensitive wetlands, such as bogs, begin showing signs of stress when the watershed exceeds 4% impervious. Fortunately, emerging watershed protection techniques offer the possibility of

of the nation's degraded waters. Though this figure - 12% - may seem small, the impact of growth upon our lives is greatly magnified by the fact that waters degraded by development are generally those located within our most densely populated areas. The first series of growth impacts come during the construction phase. Bulldozing away a forest can increase soil erosion by 1,000-fold. The mud washed from a typical construction site can damage three miles of downstream waters with recovery taking up to a century. Heavy equipment operation in wetlands and channels can exacerbate the impact, particularly if habitat is permanently altered or migration barriers are created. Once the construction phase is completed and denuded soils are stabilized with lawn, buildings, asphalt, and concrete, another set of impacts are introduced.


Covering permeable soils with *impervious* materials such as homes, parking lots, and streets prevents rainwater and snowmelt from soaking into the earth. This infiltrating rain and snowmelt serves as the source of water entering most wetlands and streams during dry weather. Thus as *impervious* areas increase within a watershed, the volume of groundwater flowing into the wetland or stream decreases. An acre of *impervious* area may reduce groundwater recharge and groundwater flow to

wetlands, streams, and tidal waters by 300,000 gallons per year. Groundwater inflow tends to be of very high quality with cool temperatures that are crucial to many aquatic species. A decline in recharge may also affect the amount of water available to those who rely upon wells.

The water which once soaked into the earth becomes stormwater runoff after *impervious* areas are constructed. This runoff washes large quantities of pollutants from rooftops, streets, and parking lots. Stormwater pollutants include nutrients, salt, oil, oxygen-consuming materials, and toxics, such as copper, lead, and zinc. Many of these contaminants settle from the atmosphere and accumulate upon *impervious* areas until the next rain washes them into a nearby waterway. Other sources include: car and truck operation; fertilizers and pesticides applied to lawns; corrosion of metal downspouts and gutters; and other sources.

Converting a forest to homes on one-acre lots can result in a 12-fold increase in nutrient loads. Such a nutrient increase

Watershed Development Impact Thresholds



having healthy, productive coldwater resources in watersheds developed beyond these thresholds. Unfortunately, few local or state government agencies require full and effective use of these techniques. But there are lots of great examples of how local organizations, such as Trout Unlimited chapters, have won advances in watershed protection. In this factsheet we'll explain how. Further information on this topic can be found on our website: www.ceds.org. Also, please feel free to give us a call at 1-800-773-4571 if you have any questions or you would like to discuss development threatening your favorite trout stream.

How Growth Impacts Trout Streams

Converting a farm or forest to a housing project, a mall, or a highway has devastated thousands of streams, rivers, lakes, wetlands, and tidal waterways. In fact, the U.S. Environmental Protection Agency cites land development as the leading cause of recent wetland losses. Development also accounts for 12%

COMMUNITY & ENVIRONMENTAL DEFENSE SERVICES

811 Crystal Palace Court • Owings Mills, Maryland 21117 • (800)773-4571 • E-mail: info@ceds.org

could cause algae to proliferate in a downstream lake or tidal waterway. As algal populations build water clarity declines, which has resulted in the loss of aquatic grasses and a dramatic shift in the species inhabiting the water body. If left unchecked even more serious effects may result such as the release of noxious odors and massive die-offs of fish and other aquatic creatures. The U.S. EPA has found that the metals copper, lead, and zinc are frequently present in runoff from impervious area at a concentration which will kill or injure aquatic organisms. Runoff from impervious surfaces also carries other forms of pollution such as heat. Runoff from an asphalt road or parking lot may have a temperature of 90°F or more in the summer. Sensitive species such as trout prefer a temperature of 68°F or less and begin dying when water temperature reaches 75°F.

Measures to Minimize Growth Impacts

A number of environmental protection measures are available to reduce the impact of watershed development upon aquatic resources. These measures are known as *Best Management Practices* or *BMPs* for short.

Construction site BMPs are designed to keep mud pollution out of nearby waterways. These BMPs generally fall into one of two categories - soil erosion control and sediment trapping measures. Erosion control BMPs are designed to protect exposed soil from the effects of rainfall and runoff. Examples of these measures include covering exposed soil with straw mulch and/or sowing grass seed. Erosion control measures can reduce mud pollution by 90% or more. Sediment trapping BMPs include the black cloth silt fence erected along the edge of small construction sites as well as settling ponds. These BMPs can keep 50% to 75% of the soil eroded on a construction site out of nearby waterways. Several studies have shown that mud pollution from construction sites must be reduced by 90% or more to protect sensitive aquatic resources. Only erosion control BMPs could achieve this goal.

Measures to manage stormwater runoff from impervious areas also fall into two categories - ponds and infiltration. Ponds can keep 40% to 60% of the nutrients and toxic metals out of nearby waterways. Infiltration measures, which force runoff to flow through sand, soil, or other filtering mediums, can capture 50% to 95% of the metals and nutrients. A reduction on the order of 90% is needed to fully protect the aquatic environment from the toxic effects of metals. Infiltration measures also maintain groundwater recharge and prevent heated runoff from entering sensitive waterways. Ponds cannot maintain recharge and the temperature of runoff stored in ponds can reach as high as 100°F.

Do These Measures Truly Prevent Growth Impacts?

In most cases the answer to this question is no. This is because few counties, cities, or states in the U.S. succeed in getting contractors to consistently use straw mulching and other erosion control BMPs on exposed construction site soils. Again, unless erosion control is used effectively some damage to aquatic resources will occur. This problem is made worse by ineffective use of sediment trapping measures. A North Carolina study found that only half the trapping measures installed on construction sites were properly applied. Most localities in the U.S. rely upon ponds to control stormwater runoff from impervious surfaces, not infiltration. And even where infiltration BMPs are

rationally required, poor inspection and maintenance results in too many failures. Earlier in this fact sheet it was explained that ponds alone cannot fully protect aquatic resources. Only infiltration measures can fully protect sensitive wetlands, streams, and estuaries. This has been borne out by several recent studies. The researchers found little difference in aquatic communities in streams draining watersheds developed with and without ponds. The ponds failed to prevent the loss of sensitive aquatic species.

Protecting a Trout Stream or Lake from Growth Impacts

While few localities manage growth in a way that preserves the health of aquatic systems, this does not mean that this goal is unattainable. In the mid-1980s, 50 Maryland volunteers mounted a campaign that quadrupled the quality of mud pollution control on hundreds of construction sites! Prince George's County, Maryland and King County, Washington are known as having two of the most innovative and effective stormwater control programs in the U.S. These counties achieved this stature in part through the high level of citizen awareness regarding the effects of stormwater upon quality of life. To protect your favorite stream, river, lake, or tidal waterway you should insist that growth either be:

- 1) Limited to that which will not exceed a watershed imperviousness of 2% - 8%; or
- 2) Local environmental protection programs must be brought up to a level which will ensure full and effective use of erosion control and infiltration BMPs along with limits on the maximum amount of growth permitted within watershed supporting highly sensitive species.

How CEDS Can Help

Mounting a campaign to achieve these two objectives can be a large undertaking. We can show you how to define the watershed of a stream, river, lake, wetland, or tidal waterway. We can also show you how to determine the current area of the watershed which is impervious and how a proposed development project would affect percent impervious area. Next, we can help you determine if highly-effective BMPs are being used in your area. Finally, we can help you build the public support needed to win limits on watershed development and to upgrade the quality of BMPs used in your area.

Our advice is always available free of charge to citizens and citizen groups. We can also provide you with a free copy of one of our many reports analyzing the effects of a proposed development project upon the aquatic environment. These reports give a clearer picture of how development impacts aquatic systems, how BMPs reduce these impacts, and what an analysis of your watershed might look like. To request a copy or to discuss your effort, call CEDS at 1-800-773-4571. These publications may also be downloaded from:

www.ceds.org